


Cable Connection Replacement

Brad Stout

Project Engineer

Louisville District

11 February 2015



US Army Corps of Engineers
BUILDING STRONG®




Presentation Outline

- Dam Facts
- Purpose of the repair
- Repair Process
- Lessons learned
- Questions/Comments



BUILDING STRONG®

Location of Cannelton



BUILDING STRONG®

Cannelton Dam Facts

- 12 Tainter Gates
- 100 ft wide x 42 ft tall
- Gate weight 820,000 lbs
- Supported by 24 – 1 3/8” wire rope
- Operated with electric hoist machinery



BUILDING STRONG®

Purpose: Cannelton

- 2005 inspection of Markland Cable Connections identified severe deterioration. Cannelton shares the same design.



Markland 2005



Markland 2005



BUILDING STRONG®

Repair Process: Cannelton


- Set bulkheads and raise tainter gate to stops
- Set hydraulic tainter gate maintenance pedestals and lower gate onto pedestals
- Inspect wire rope
- Gouge wire rope above the upper connection block and remove tension bolts (for re-use)
 - Press wire rope socket from upper connection block for re-use
 - Remove keepers and upper retaining block from machinery drum
 - Using the piggy back crane hoist wire rope through the machinery room and onto the flat deck barge
 - Cut retaining block from wire rope and press out socket for re-use
 - Cut new wire rope to length
- Install upper connection block and retaining blocks on to wire rope, broom both ends, pour wire lock/socket lock and let cure
- Install new pin and connection blocks



BUILDING STRONG®

Repair Process: Cannelton

- Set bridges, take tension readings, and adjust tension
- Tilt pedestals up-stream and lower gate down to sill, raise gate take tension readings (make adjustments if needed)
- Install finger plate and knife blade plate
- Fill void with tar for sealant
- Remove pedestals



BUILDING STRONG®

Existing Conditions



Damaged knife blade plate, and missing sealing plate



Missing knife blade plate



BUILDING STRONG®

Existing Conditions



Damaged wire rope



BUILDING STRONG®

Repairs



Hydraulic maintenance pedestals



Piggy back crane hoisting wire rope through machinery room



BUILDING STRONG®

Repairs

Broom wire rope end



Socket lock



BUILDING STRONG®

Repairs



Bridge for tension readings



Tilting function of
hydraulic pedestal



BUILDING STRONG®

Finish Product

Replaced sealing plate and tar for sealant




Replaced caulking plate




BUILDING STRONG®

Location of Newburgh



BUILDING STRONG®

Location of John T. Myers



BUILDING STRONG®

Newburgh Dam Facts

- 9 Tainter Gates
- 110 ft wide x 32 ft tall
- Gate weight 788,000 lbs
- Supported by 26 – 1 3/8" wire rope
- Operated with electric hoist machinery



BUILDING STRONG®

John T. Myers Dam Facts

- 10 Tainter Gates
- 110 ft wide x 32 ft tall
- Gate weight 788,000 lbs
- Supported by 26 – 1 3/8" wire rope
- Operated with electric hoist machinery



BUILDING STRONG®

Purpose: Newburgh/ John T. Myers

- OCA Rating of F, the “swivel (pivot) blocks” were seized preventing rotation and the wire rope was identified as bad at Newburgh.



John T. Myers 2014



Newburgh 2014




BUILDING STRONG®

[illegible]

- 

BUILDING STRONG®

Existing Pivot Block Design




BUILDING STRONG®

Replacement Pivot Block Design

2009 Re-design by Brian
Holcomb and Ross Woodbury
after replacing pivot blocks on
gate 10 at John T. Myers

Sliding Block Keeper
Kamatics Greaseless Bushing



TAINTER GATE
PIVOT BLOCK ASSEMBLY



BUILDING STRONG®

Repair Process: John T. Myers

- Set bulkheads and raise tainter gate to stops
- Set tainter gate maintenance pedestals and lower gate onto pedestals
- Gouge tension bolts
- Oxy-Lance existing pivot block and pins
- Sandblast, paint cable attachment bracket, and install anodes
- Install new pin and pivot blocks
- Install new tension bolts
- Raise tainter gate, place bridges, and take tension readings
- Place tainter gate onto pedestal to make adjustments (repeat as needed)
- Install keepers
- Raise tainter gate and remove pedestal



BUILDING STRONG®

Repairs



Lock personnel placing Bulkheads



Placement of maintenance
Pedestal



BUILDING STRONG®

Repairs



Maintenance Pedestal



Tension Bolts



Oxy-Lancing Pivot blocks



BUILDING STRONG®

Repairs



Tension
Readings

Bridge for Tensioning



Finish Product



BUILDING STRONG®

Repair Process: Newburgh

- Set bulkheads and raise tainter gate to stops
- Set tainter gate maintenance pedestals and lower gate onto pedestals
- Gouge tension bolts and wire rope above the upper connection block
 - Press wire rope socket from upper connection block for re-use
 - Remove keepers and upper retaining block from machinery drum
 - Using the piggy back crane hoist wire rope through the machinery room and onto the flat deck barge
 - Cut retaining block from wire rope and press out socket for re-use
 - Cut new wire rope to length
- Oxy-Lance existing pivot block and pins
- Sandblast, paint cable attachment bracket, and install anodes
- Install upper connection block and retaining blocks on to wire rope, broom both ends, pour wire lock and let cure
- Install new pin and pivot blocks



BUILDING STRONG®

Repair Process: Newburgh

- Using piggy back crane hoist wire rope up to machinery room and install retaining block onto machinery drum with keepers
- Install new tension bolts
- Raise tainter gate, place bridges, and take tension readings
- Place tainter gate onto pedestal to make adjustments (repeat as needed)
- Install keepers
- Raise tainter gate and remove pedestal



BUILDING STRONG®

Repairs



Placement of maintenance pedestal



Tension bolts



BUILDING STRONG®

Repairs



Piggy back crane hoisting old wire rope down to flat deck barge



Socket pressed out of upper connection block



BUILDING STRONG®

Repairs



Oxy-Lancing



Sandblast and Paint



New Pivot blocks and Anodes



BUILDING STRONG®

Repairs



Damaged wire rope



BUILDING STRONG®

Repairs



Broom wire rope



Socket Lock



BUILDING STRONG®

Repairs



Bridge for tension readings

Finish product




BUILDING STRONG®

Pivot Blocks



Before



After



BUILDING STRONG®

Work Plan Lessons Learned

- At Newburgh the sockets had to be heated prior to pressing
- Method for bridging the wire rope for tensioning (isolating the wire rope improved tension readings)
- The use of hydraulic pedestals on tainter gates with the connections on the up-stream skin sheet do not offer any significant advantage
- Cure times for paint and wire lock had to be adjusted due to colder weather



BUILDING STRONG®

Technical Aspects

- Properly placement of tainter gate maintenance pedestals, maximizing the bearing surface and avoiding possible debris on dam sill
- Oxy-Lancing of the pivot block, ~3" between brackets
- Cure time of wire lock/ socket lock
- Average tension within plus/minus 7% of each wire rope
- Elevation of Dam bridge and crane boom elevation during placement of pedestals



BUILDING STRONG®

Questions / Discussions



BUILDING STRONG®